

6700050
UNIVERSAL



6700050
UNIVERSAL

UNIVERSAL Logo

TOOLS REQUIRED:

8mm Socket and Ratchet

PARTS LIST:

(2) 6/32" Nylon Lock Nuts
(2) 1" Fender Washers
(1) Logo

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Insert the logo onto the mesh grille, the threaded studs will insert through the mesh holes. From the backside install the two 1" fender washers and the nylon lock nuts on the threaded studs and tighten.