

20463

02-05 DODGE
RUMBLE BEE
HOOD SCOOP



20463

02-05 DODGE
RUMBLE BEE
HOOD SCOOP

BILLET INSERT – HOOD SCOOP

Tools Required:

Phillip Screw Driver
Socket or wrench
1/8 Drill Bit

Hardware / Parts List:

- 1 Billet Insert (3 bars)
- 2 6-32 X 1.5" Machine Screw
(SHAVED HEAD SCREW)
- 2 #10 Flat Washers
- 2 6-32 Nylon Locking Nuts

Read and understand instructions before attempting installation

Step 1

Remove the hood scoop from hood. Test fit the billet into the opening. With a marker, mark the centers of mounting tabs on plastic for drilling. Remove the billet and drill a 1/8" hole. Center the billet into scoop. Place the custom machine screws through the front of the billet and plastic backing. Place a flat washer and a nylon locking nut on each screw and tighten.

Step 2

Re-install the hood scoop to vehicle.

Thank you for purchasing your T-Rex billet grille 9/26/07

