

# **20500**

**92-07 FORD**  
**ECONOLINE**

**E150-250 Van**  
**BILLET INSERT**



# **20500**

**92-07 FORD**  
**ECONOLINE**

**E150-250 Van**  
**BILLET INSERT**

**Tools Required:**

Phillips Screw Driver  
Drill  
1/8" Drill Bit

**Parts List:**

1 - Billet Insert (22 Bars)  
6 - #8 x 3/4 Phillips Screws

**Read and understand instructions before attempting installation**

**Note: THIS BILLET GRILLE REPLACES THE ENTIRE GRILLE SHELL. After installation; Opening the hood will require the use of a long screw driver or similar tool to insert in between the bars of the billet grille to release the hood latch.**

**Step1**

Remove the grille shell from the vehicle (**This billet insert replaces the entire factory grille shell**).

**Step2**

Place the billet insert into the opening. Align the insert so it is flush with the headlight and lower panel. Mark and drill the four lower mounting brackets and fasten to the header panel using the screws provided. Pull the top of the billet grille in and align with the headlights. Drill and fasten the two top brackets to the header panel using the screws.

**Step3**

Your installation is now complete. *Thank you for purchasing a T-Rex billet grille.*