

# 21126

(14216P)

## **03-12 CHEVY EXPRESS VAN OVERLAY**



# 21126

(14216P)

## **03-12 CHEVY EXPRESS VAN OVERLAY**

### **Tools Required:**

5/16" Nut Driver or Just Pliers  
Phillip Screw Driver

### **Parts list:**

1 - Upper Billet Insert (8 bars)  
1 - Lower Billet Insert (11 bars)  
8 - 6-32 x 1.5" Machine Screws  
8 - 6-32 Nylock Nuts  
8 - #6 Flat Washers  
8 - 2" Flat Flange Brackets


### **Read and understand instructions before attempting installation**

#### **Step 1.**

Identify the upper and lower inserts. Test fit each billet in the openings in the grille shell. Open the hood and remove the black plastic radiator top cover.

#### **Step2.**

Set the lower billet in the bottom opening of the grille shell. Insert four screws in the brackets welded to the back of the billet. Now place a flange bracket and flat washer from the rear of the grille; then thread a Nylock nut on each screw. Snug each nut down so the billet insert is held firmly in place.



#### **Step 3.**

Repeat the instructions from Step2 on the upper insert.

#### **Step 4.**

Make sure the inserts are straight and all fasteners are tight. Re-install the top cover on the vehicle. Installation is now complete. *Thank you for purchasing a T-Rex billet grille.*