

25165

04-06 PONTIAC

GTO



25165

04-06 PONTIAC

GTO

2004-2006 PONTIAC GTO BUMPER INSERT

Tools Required:

Phillip Screw Driver
Slotted Screwdriver
Needle Nose Pliers

Hardware / Parts List:

1 Bumper Insert (11 bars)
4 6-32 x 2" Machine Screws
4 #8 U-Nuts Screws
4 2" Flange Brackets

Read and understand instructions before attempting installation

Step 1

If you have purchased the main grille kit with the bumper insert, start the installation of the top grilles as indicated. If not, remove the fasteners securing the bumper cover along the bottom to gain access.



Step 2

Slide the U-nuts over the holes on the flange brackets. Center the bumper insert over the grille mesh. Insert the machine screws into the tabs welded to the insert. From the back, fasten the flange brackets to the screws. Wrap the flanges around the plastic bars and tighten.

Step 3

Re-install the fasteners securing the bumper cover.

Thank you for purchasing your T-Rex billet grille.

T-Rex Truck Products Inc. 5/3/05

