

21573
21573B
2013 FORD
F-150



21573
21573B
2013 FORD
F-150

2013 FORD F-150

Billet Grille Overlay

Install time: 25 Mins.

TOOLS REQUIRED:

Plastic Prybar
Die Grinder
Drill & 1/8 Drillbit

PARTS LIST:

(4) Billet Grilles
(8) L-Brackets
(8) 1.5 (6Head) Screws
(8) U-Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1 Remove Factory Grille Shell

- Insert the U-Nuts through the L-Brackets with the Holes. (Fig. 1)
 - Place the #8 Screw through the Brackets that are on the Billet Grille. (Fig. 2)
 - From behind the Grille, Thread the 1.5 Screw through the L-Bracket so it Latches onto the Factory Grille. (Fig. 3)
- Repeat for remaining Screws.

INSTALLATION COMPLETE

