

21210

11-12 GMC
SIERRA HD



21210

11-12 GMC
SIERRA HD

11-12 GMC SIERRA HD Upper Class Overlay Billet Grille

TOOLS REQUIRED:

Phillips Screwdriver
Socket & Ratchet set
Plastic Prybar

PARTS LIST

(2) 4.5 L-Brackets (1) Billet Grille
(5) 1.5 J-Hooks
(7) U-nuts
(7) 1' #8 6 head Screws

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

Step 1

Remove (10) clips from plastic cover. (Fig. 1)
Remove plastic cover.
Remove (2) center 10mm bolts along the top of grille. (Fig. 2)

Step 2

Insert the (7) U-Nuts through the threaded hole on the
L-brackets and J-hooks. (Fig. 3)

Step 3

Place overlay grille onto factory grille. (Fig. 4)

Step 4

Insert 1' #8 6 head screw into each hole on the overlay grille.
(Fig. 5)
Thread a J-Hook onto each screw so it latches onto the
plastic bar.(Fig. 6)

Step 5

Install (2) 4.5 L-Brackets above the overlay grille. (Fig. 7)
Re-Install the (2) center 10mm Bolts through the (2) 4.5
L-Brackets along the top of grille.
Re-Install the plastic cover

Installation Complete

